


S N I P E R
(NAKED SNIPER)
SHISHA USER GUIDE

www.medusepipes.com


1. WATER FILLING

- > Remove the upper stainless steel part of the water pipe
- > Fill the water pipe stainless steel corpus up to the marked line (0.4 l)
- > A red rubber cap, which is used to open or close the vent holes, is applied on the head tube.
In position **1**, the vent holes of the head are open and the pipe is in active mode
In position **2**, the vent holes are closed and the pipe is ready to be transported
- > Put the upper part of the water pipe back again
- > Total height: **40 cm** (15.8")




2. WASHABLE HOSE SET UP

- > Screw the stainless steel grip in or put the breathing mask on the hose
- > A tip may be inserted into the grip
- > Hose length: **128 cm** (50.4")




3. HOSE INSTALLATION

- > Screw out the stainless steel stopper
- > Screw in the complete hose or just the stainless steel grip
- > At one end the hose is equipped with a rotary socket, which allows its much easier assembly into the water pipe corpus




4. HEAD SET UP



- > Put the lower stainless steel screen filter in the head, so that it would rest at the bottom of the head (the bent part down, see the picture)
- > Fill the head with tobacco (7-8 g = approx 50-60 min. of smoking)
- > Put the upper stainless steel screen filter into the head (recommended distance of 1-2 mm between tobacco and the screen filter, tobacco will not be burned onto the screen filter)
- > Light the charcoal (recommended self-lighting charcoal 33 mm) and place it into the upper screen filter
- > The water pipe is ready to be smoked




5. STORAGE SPACE

- > Put the metal box inside the red rubber plug
- > Roll up the hose into the storage space
- > Pull in the stainless steel grip
- > Close the storage space by the rubber plug
- > Close the vent holes on the head tube by the rubber cap and pull the head into the pipe again
- > Screw up the plugs
- > SNIPER is ready to be transported







1x



1x




1x




1x

3x




1x

3x




1x



1x


1x

1x




1x


1x





2x



1x




1x




1x



1x

1x







SNIPER DUALITY
 SET INCLUDES




1x



1x




1x




1x

3x



1x

3x




1x

1x


1x

1x




1x


1x





2x



1x



1x



1x

1x

1x

